

MARINE

IGNITION STARTER SWITCH



FE-B1101 FE-B1102 FE-B1103 FE-B1104 FE-B1106 FE-B1107



FE-B1108 FE-B1109 FE-B1111 / B1112 FE-B1113 FE-B1114

MARINE

PUSH BUTTON SWITCH



FE-B1201 FE-B1201-1 FE-B1202 FE-B1203 FE-B1203-1 FE-B1203-2 FE-B1203-3 FE-B1205



FE-B1206 FE-B1207 FE-B1208 FE-B2201 FE-B2202-1 FE-B2203 FE-B2204

MARINE

PUSH PULL SWITCH



FE-B1801 FE-B1801W FE-B1802 FE-B1803 FE-B1804



FE-B1803M FE-B1805 FE-B1806 FE-B1807

MARINE

EMERGENCY CUT-OFF SWITCH



FE-B1901 FE-B1902 FE-B1903 FE-B1904



FE-B1905 FE-B1906 FE-B1907

MARINE

BATTERY ISOLATION SWITCH



FE-B1601 FE-B1602 FE-B1604 FE-B1605



FE-B2601 FE-B2602 FE-B2603

MARINE

PILOT LAMP / TOGGLE SWITCH



FE-B1001R FE-B1701 FE-B1702 FE-B1703 FE-B1704

MARINE

BATTERY ISOLATION SWITCH :

FE-A3601 / FE-A3601C / FE-A3602 / FE-A3603 / FE-A3604 / FE-A3604B / FE-A3605 / FE-A3605B

TOGGLE SWITCH : FE-A1759

AT AUTO